

Pia-central hood

Usage- and servicemanual



Lights OFF/ON

Cooking

The cooker hood is equipped with a flow control fire valve.

Lights

Lights: LED 2x3W 3000K, GU10 fittings. Only use lights approved by Airfi Oy.
Cut power to the hood while changing lights.

Service and cleaning

To ensure the function of the cooker hood, the hood must be regularly serviced

Clean the grease filter at least once a month by hand or in the dishwasher. Release the grease filter with the quick-release levers. The colour of the filter might change after washing but this does not affect the performance of the filter.

Use a cleaning agent for painted and plastic surfaces to clean the rest of the hood.



Note!

Only use lights approved by Airfi Oy.



Note!

Leaving the filters uncleaned is a fire hazard.



Note!

Open flames beneath the hood is strictly forbidden.